







1000 LUMEN RECHARGEABLE LED

WORK LIGHT

USER GUIDE

1000 LUMEN RECHARGEABLE LED WORK LIGHT

USER GUIDE

Thank you for purchasing the MICHELIN 1000 Lumen Rechargeable LED Work Light. With normal care and proper treatment, it will provide years of reliable service. Please read all operating instructions carefully before use.

WARNING & SAFETY INFORMATION!

- Always consult your local highway safety guidelines for appropriate use and placement when using in emergency roadside situations.
- This product is not a toy. Do not allow children to play with this item.
- Do not store in direct sunlight or near a heat source.
- Use for intended purposes only.
- This product contains strong magnets that may cause interference with pacemakers and other implanted medical devices when placed within a close proximity. Keep this product at least 6 inches from your chest if you have a pacemaker.

FEATURES

- Dimmable Work Light
- Hazard Light
- Rechargeable Li-ion battery
- Strong magnets

- Folding, adjustable stand
- Adjustable strap handle
- Visibility up to 1 mile
- 4 stage battery status indicator

SPECIFICATIONS

Brightness (Lumens)	Work Light: 1.000 lm (dimmable to 50 lm) Hazard Light: 60 lm
Light patterns	4 (3x hazard light, 1x work light)
Visibility	up to 1 mile
Battery	4.400 mAh, Li-Ionen (3.7 V)
Impact Resistance	3 feet
IP Rating	IP X2
Charge Time	6 hours
Unit size	20,3 x 13,5 x 3,5 cm
Unit weight	450 g

OPERATION

WORK LIGHT:

- To turn unit on/off: Press the 🔀 power button on the left.
- To dim: Press and hold until desired brightness is reached. Light will flash when at lowest setting.
- To increase brightness: press and hold until desired brightness is reached.

HAZARD LIGHT:

- To turn unit on/off: Press the 🔀 power button on the right.

1x: SOLID-ON 2x: FLASH 3x: TRIPLE-PULSE

The battery status indicators illuminate when the light is in use.

LIGHT PATTERNS (RUN TIME)

WORK LIGHT (2–40 HOURS) HAZARD LIGHT:

SOLID-ON (5 HOURS) FLASH (10 HOURS)

TRIPLE-PULSE (18 HOURS)

CHARGING THE INTERNAL BATTERY

Please charge before initial use. In order to keep the charge, be sure to fully recharge the unit every 6 to 12 months, even if the unit has not been used.

- 1. Locate the attached USB cord on the side and plug into a USB power port such as a USB wall charger, USB car charger or power bank.
- The charge indicator LEDs will illuminate to show the level of charge (25–100 %). While recharging, the next LED will flash, followed by the next until fully charged. It is fully charged when all 4 LEDs illuminate solid.
- 3. Return the USB cord into its storage location.

HOW TO ADJUST THE STRAP



- 1. Lift tab.
- 2. Adjust strap.
- 3. Push tab down to lock.

MAINTENANCE

- All batteries discharge over time. Be sure to fully recharge the unit every 6 to 12 months, even if the unit has not been used.
- Use a slightly damp cloth with mild detergent to clean the outer surfaceas needed.



Customer enquiries:

We're at your service. Let us help you find a better way forward.

Tel: +49 (0) 7131 27588-44 Michelin@helix-automotive.com Manufactured and distributed under licence by Helix Automotive GmbH, Fischeräcker 4, DE-74223 Flein

© 2021 Michelin, www.michelin-lifestyle.com

MICHELIN and/or the Michelin Man Device and/or BIBENDUM are trademark(s) owned by, and used with the permission of, the Michelin Group.

