

AIR PUMP

USER GUIDE

THANK YOU FOR PURCHASING THE MICHELIN RECHARGEABLE BATTERY AIR PUMP.

Please read the operating instructions carefully before using your air pump. Improper use can cause damage to property and possibly harm the user.

WARNING & SAFETY INFORMATION!

- Read the user manual carefully. Bike manufacturers may have specific precautions and instructions about the inflation of tyres.
- Observe the pressure recommended by the tyre manufacturer (check marking on tyres).
- Use the device as directed. Do not inflate car tyres and other vehicles with bigger tyres.
- Do not leave the device unattended during operation.
- After periods of time, the air pump housing can become hot. Continuous operation of the air pump should not exceed 7 8 minutes.
- The device contains a lithium battery, periodic charging is necessary every three months to maintain battery life.
- Do not recharge the device immediately after continuous operation. Allow it to cool for about 20 30 minutes.
- Only charge this air pump with the charger that is included in the package.
- Keep the air pump away from direct contact with water and other liquids. Do not operate it during heavy rainfall.
- Never allow children to use this air pump.

FUNCTIONS



- 1. Mounting adaptor
- 2. Fastening straps to frame
- 3. Mounting holes
- 4. Linear gauge (bar, psi)
- 5. Double nozzle (Schrader or Presta)
- 6. LED light

- 7. Air hose outlet
- 8. Input for charging
- 9. Light button
- 10. On/Off button
- 11. Electric pump
- 12. Charger (AC 100 220 V)

SPECIFICATIONS

Lithium battery: 12.8 V/500 mAh

Recharging time: 2 – 3 hours

Maximum pressure: 120 psi/8 bar (kg/cm²)

Continuous operation time: 7 – 8 mins

Operation temperature: $-10 \,^{\circ}\text{C} - +45 \,^{\circ}\text{C}$ Recharging temperature: $0 \,^{\circ}\text{C} - +40 \,^{\circ}\text{C}$

Charger input: AC 100 – 240 V; 50/60 Hz; max. 0.3 A

Charger output: DC 14.5 V; 0.4 A

Weight: 0.6 kg

HOW TO USE

1. Take off protection rubber cover from air outlet.

- 2. Thread air hose together with air pump.
- 3. Choose the correct nozzle compatible with your bike tyre valve (Schrader or Presta).
- 4. Screw in the nozzle to the tyre valve. Make sure the connection is tight and there is no air leakage.
- 5. Open the plastic cover from the opposite side.
- 6. Switch on the air pump by pressing the blue on/off button. Inflation starts.
- 7. Control pressure level with linear gauge on the air hose.
- 8. Switch off the air pump by pressing the blue on/off button again. Inflation stops.
- 9. For operation in dark conditions use the built-in LED light. Switch it on/off by pressing the small yellow light button.

28" bicycle tyre:

The air pump needs to cool down after continous inflation of 2 tyres.

29" x 2,5 bicycle tyre:

The air pump needs to cool down after inflation of 1 tyre.

THE FOLLOWING TYRES CAN BE FILLED WITH ONE BATTERY CHARGE:







up to 6 tyres



up to 4 tyres



up to 2 tyres

DE: BEDIENUNGSANLEITUNG – FR : MODE D'EMPLOI – IT: MANUALE D'USO – ES: MANUAL DE USUARIO –

TR: KULLANIM KILAVUZU



AUFLADBARE AKKU LUFTPUMPE

https://www.helix-automotive.com/qr/61005/userguide/de/



POMPE À AIR SUR BATTERIE RECHARGEABLE

https://www.helix-automotive.com/qr/61005/userguide/fr/



POMPA D'ARIA A BATTERIA RICARICABILE

https://www.helix-automotive.com/qr/61005/userguide/it/



BOMBA DE AIRE DE BATERÍA RECARGABLE

https://www.helix-automotive.com/qr/61005/userguide/es/



AKÜLÜ HAVA POMPASI ŞARJ EDILEBILIR

https://www.helix-automotive.com/qr/61005/userguide/tr/



Customer enquiries:

We're at your service. Let us help you find a better way forward.

Tel: +49 (0) 7131 27588-44 Michelin@helix-automotive.com Manufactured and distributed under licence by Helix Automotive GmbH, Fischeräcker 4, DE-74223 Flein

© 2021 Michelin, www.michelin-lifestyle.com

MICHELIN and/or the Michelin Man Device and/or BIBENDUM are trademark(s) owned by, and used with the permission of, the Michelin Group.

